

Многофункциональные дверные модули MGB2-L.H.-B

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eai@nt-rt.ru || сайт: <https://euchner.nt-rt.ru/>

COMPLETE SETS MGB2-L.H.-B.



- Modular design with submodules
- Easy to expand
- Up to 10 BR devices can be connected in series in a chain
- Submodule replacement in operation
- For doors hinged on the right as well as on the left
- Integrated alignment aid



169586

MGB2-IH-BR-U-S5-PY-L-169586

Complete set MGB2-I...-BR (M23, 2 pushbuttons, door hinge on left)

- Interlocking (without guard locking)
- 2 illuminated white pushbuttons with symbol
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: left
- Unicode



169585

MGB2-IH-BR-U-S5-PY-R-169585

Complete set MGB2-I...-BR (M23, 2 pushbuttons, door hinge on right)

- Interlocking (without guard locking)
- 2 illuminated white pushbuttons with symbol
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: right
- Unicode



165701

MGB2-IHE-BR-U-S0-LY-R-165701

Complete set MGB2-IHE...-BR (3 pushbuttons, with escape release, closed-circuit current principle, door hinge on right)

- Interlocking (without guard locking)
- 3 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: right
- Unicode
- incl. escape release and inner door handle



167026

MGB2-L1H-BP-U-S4-OY-L-167026

Complete set MGB2-L1...-BP (M23, closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: left
- Unicode



167025

MGB2-L1H-BP-U-S4-OY-R-167025

Complete set MGB2-L1...-BP (M23, closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: right
- Unicode



166102

MGB2-L1H-BP-U-S9-OY-L-166102

Complete set MGB2-L1...-BP (2 x M12, closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Connection submodule with plug connectors 2 x M12
- Adjustable door hinge; factory setting: left
- Unicode



166100

MGB2-L1H-BP-U-S9-OY-R-166100

Complete set MGB2-L1...-BP (2 x M12, closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Connection submodule with plug connectors 2 x M12
- Adjustable door hinge; factory setting: right
- Unicode



161775

MGB2-L1H-BR-U-S0-DB-L-161775

Complete set MGB2-L1...-BR (2 pushbuttons, emergency stop, closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Connection for signal light/enabling switch
- Adjustable door hinge; factory setting: left

- Unicode



161774

MGB2-L1H-BR-U-S0-DB-R-161774

Complete set MGB2-L1...-BR (2 pushbuttons, emergency stop, closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Connection for signal light/enabling switch
- Adjustable door hinge; factory setting: right
- Unicode



167753

MGB2-L1H-BR-U-S0-OY-L-167753

Complete set MGB2-L1...-BR (closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: left
- Unicode



167752

MGB2-L1H-BR-U-S0-OY-R-167752

Complete set MGB2-L1...-BR (closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: right

- Unicode



161787

MGB2-L1H-BR-U-S1-DY-L-161787

Complete set MGB2-L1...-BR (M23, 2 pushbuttons, emergency stop, closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: left
- Unicode




161786

MGB2-L1H-BR-U-S1-DY-R-161786

Complete set MGB2-L1...-BR (M23, 2 pushbuttons, emergency stop, closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: right
- Unicode



164745

MGB2-L1HE-BP-M-S2-RY-L-164745

Complete set MGB2-L1...-BP (M23, 1 pushbutton, closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring

- 1 illuminated pushbuttons
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: left
- Escape release
- Multicode



164744

MGB2-L1HE-BP-M-S2-RY-R-164744

Complete set MGB2-L1...-BP (M23, 1 pushbutton, closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- 1 illuminated pushbuttons
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: right
- Escape release
- Multicode



164370

MGB2-L1HE-BR-U-S0-DY-L-164370

Complete set MGB2-L1HE-BR (2 pushbuttons, emergency stop, with escape release, closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: left
- Unicode
- incl. escape release and inner door handle



164396

MGB2-L1HE-BR-U-S0-DY-L-164396

Complete set MGB2-L1HE...-BR (2 pushbuttons, with escape release, closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: left
- Unicode
- incl. escape release and inner door handle



164367

MGB2-L1HE-BR-U-S0-DY-R-164367

Complete set MGB2-L1HE-BR (2 pushbuttons, emergency stop, with escape release, closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: right
- Unicode
- incl. escape release and inner door handle



164393

MGB2-L1HE-BR-U-S0-DY-R-164393

Complete set MGB2-L1HE...-BR (2 pushbuttons, with escape release, closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: right
- Unicode
- incl. escape release and inner door handle



166329

MGB2-L1HE-BR-U-S0-OY-L-166329

Complete set MGB2-L1HE...-BR (with escape release, closed-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: left
- Unicode
- incl. escape release and inner door handle



166327

MGB2-L1HE-BR-U-S0-OY-R-166327

Complete set MGB2-L1HE...-BR (with escape release, closed-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: right
- Unicode
- incl. escape release and inner door handle



161777

MGB2-L2H-BR-U-S0-DB-L-161777

Complete set MGB2-L2...-BR (2 pushbuttons, emergency stop, open-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels

- Cable entry M20 x 1.5 (order cable gland separately)
- Connection for signal light/enabling switch
- Adjustable door hinge; factory setting: left
- Unicode



161776

MGB2-L2H-BR-U-S0-DB-R-161776

Complete set MGB2-L2...-BR (2 pushbuttons, emergency stop, open-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Connection for signal light/enabling switch
- Adjustable door hinge; factory setting: right
- Unicode



167755

MGB2-L2H-BR-U-S0-OY-L-167755

Complete set MGB2-L2...-BR (open-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: left
- Unicode



167754

MGB2-L2H-BR-U-S0-OY-R-167754

Complete set MGB2-L2...-BR (open-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring

- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: right
- Unicode



161789

MGB2-L2H-BR-U-S1-DY-L-161789

Complete set MGB2-L2...-BR (M23, 2 pushbuttons, emergency stop, open-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: left
- Unicode



161788

MGB2-L2H-BR-U-S1-DY-R-161788

Complete set MGB2-L2...-BR (M23, 2 pushbuttons, emergency stop, open-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Connection submodule with plug connector M23
- Adjustable door hinge; factory setting: right
- Unicode



164385

MGB2-L2HE-BR-U-S0-DY-L-164385

Complete set MGB2-L2HE-BR (2 pushbuttons, emergency stop, with escape release, open-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: left
- Unicode
- incl. escape release and inner door handle



164402

MGB2-L2HE-BR-U-S0-DY-L-164402

Complete set MGB2-L2HE...-BR (2 pushbuttons, with escape release, open-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: left
- Unicode
- incl. escape release and inner door handle



164378

MGB2-L2HE-BR-U-S0-DY-R-164378

Complete set MGB2-L2HE-BR (2 pushbuttons, emergency stop, with escape release, open-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- Emergency stop according to ISO 13850
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: right
- Unicode
- incl. escape release and inner door handle



164399

MGB2-L2HE-BR-U-S0-DY-R-164399

Complete set MGB2-L2HE...-BR (2 pushbuttons, with escape release, open-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- 2 illuminated pushbuttons
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: right
- Unicode
- incl. escape release and inner door handle



166335

MGB2-L2HE-BR-U-S0-OY-L-166335

Complete set MGB2-L2HE-BR (with escape release, open-circuit current principle, door hinge on left)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)
- Adjustable door hinge; factory setting: left
- Unicode
- incl. escape release and inner door handle



166334

MGB2-L2HE-BR-U-S0-OY-R-166334

Complete set MGB2-L2HE-BR (with escape release, open-circuit current principle, door hinge on right)

- Guard locking with guard lock monitoring
- 3 adhesive labels
- Cable entry M20 x 1.5 (order cable gland separately)

- Adjustable door hinge; factory setting: right
- Unicode
- incl. escape release and inner door handle

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eai@nt-rt.ru || сайт: <https://euchner.nt-rt.ru/>