

Считывающие головки типа CMS, с герконовыми контактами

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eai@nt-rt.ru || сайт: <https://euchner.nt-rt.ru/>

READ HEADS CMS WITH REED CONTACTS



Description

The read head is fastened to the fixed part of the guard and is connected to the evaluation unit via a two-core screened cable. The actuator fastened to the guard is moved towards the read head by closing the door. When the operating distance is reached, power is supplied to the actuator via the read head and the read head transfers the actuator's data to the evaluation unit.



084583

CMS-R-AXD-03V

Read heads CMS, design A - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in parallel
- Connecting cable
- Cable type: PVC



085732

CMS-R-AXD-05V

Read heads CMS, design A - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in parallel
- Connecting cable
- Cable type: PVC



102385

CMS-R-AXE-01V

Read heads CMS, design A - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in parallel
- Connecting cable
- Cable type: PVC



084584

CMS-R-AXE-03V

Read heads CMS, design A - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in parallel
- Connecting cable
- Cable type: PVC



103859

CMS-R-AXE-05P

Read heads CMS, design A - with NO contact combinations, PUR

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in parallel
- Connecting cable

- Cable type: PUR



085733

CMS-R-AXE-05V

Read heads CMS, design A - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in parallel
- Connecting cable
- Cable type: PVC



100742

CMS-R-AXE-SC

Read heads CMS, design A - with NO contact combinations, M8

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in parallel
- With plug connector M8



084585

CMS-R-AXF-03V

Read heads CMS, design A - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in series
- Connecting cable
- Cable type: PVC

**085734**

CMS-R-AXF-05V

Read heads CMS, design A - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in series
- Connecting cable
- Cable type: PVC

**100743**

CMS-R-AXF-SC

Read heads CMS, design A - with NO contact combinations, M8

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in series
- With plug connector M8

**085735**

CMS-R-AXG-05V

Read heads CMS, design A - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in series
- Connecting cable
- Cable type: PVC



100744

CMS-R-AXG-SC

Read heads CMS, design A - with NO contact combinations, M8

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 88 x 25 mm
- NO contacts wired in series
- With plug connector M8



084587

CMS-R-AXH-03V

Read heads CMS design A - with NC/NO contacts, PVC

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cube-shaped version, 88 x 25 mm
- Connecting cable
- Cable type: PVC



085736

CMS-R-AXH-05V

Read heads CMS design A - with NC/NO contacts, PVC

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cube-shaped version, 88 x 25 mm
- Connecting cable
- Cable type: PVC



100745

CMS-R-AXH-SC

Read heads CMS, design A - with NC/NO contacts, M8

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cube-shaped version, 88 x 25 mm
- Plug connector M8

**105090**

CMS-R-AZA-01PL-AS1

Non-contact safety switch CMS-R-AZA-01PL-AS1, with connecting cable and plug connector M12

- Safety switches with integrated read head and integrated evaluation unit.
- LED diagnostic displays
- Operating distance 9 mm

**124191**

CMS-R-AZA-02VL

Read heads, design A, for ESM, PVC

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 88 x 25 mm
- Connecting cable
- 1 LED
- Cable type: PVC

**103864**

CMS-R-AZA-05PL

Read heads, design A, for ESM, PUR

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 88 x 25 mm
- Connecting cable

- 1 LED
- Cable type: PUR



094702

CMS-R-AZA-05VL

Read heads, design A, for ESM, PVC

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 88 x 25 mm
- Connecting cable
- 1 LED
- Cable type: PVC



103865

CMS-R-AZA-10PL

Read heads, design A, for ESM, PUR

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 88 x 25 mm
- Connecting cable
- 1 LED
- Cable type: PUR



095558

CMS-R-AZA-10VL

Read heads, design A, for ESM, PVC

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 88 x 25 mm
- Connecting cable
- 1 LED
- Cable type: PVC



106738

CMS-R-AZA-ST0,2VL

Read heads, design A, for ESM, PVC, plug connector M12

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 88 x 25 mm
- Plug connector M12
- 1 LED
- Cable type: PVC



102275

CMS-R-AZC-SC

Read heads, design A, for ESM, M8

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 88 x 25 mm
- Plug connector M8



085530

CMS-R-BXI-03V

Read heads CMS design B - with NC/NO contacts, PVC

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cube-shaped version, 36 x 26 mm
- Connecting cable
- Cable type: PVC



085737

CMS-R-BXI-05V

Read heads CMS design B - with NC/NO contacts, PVC

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cube-shaped version, 36 x 26 mm
- Connecting cable
- Cable type: PVC

**115117**

CMS-R-BXI-07P

Read heads CMS, design B - with NC/NO contacts, PUR

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cube-shaped version, 36 x 26 mm
- Connecting cable
- Cable type: PUR

**100696**

CMS-R-BXI-SC

Read heads CMS, design B - with NC/NO contacts, M8

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cube-shaped version, 36 x 26 mm
- Plug connector M8

**103867**

CMS-R-BXO-05P

Read heads CMS, design B - with NO contact combinations, PUR

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 36 x 26 mm
- NO contacts wired in parallel
- Connecting cable

- Cable type: PUR



092023

CMS-R-BXO-05V

Read heads CMS, design B - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 36 x 26 mm
- NO contacts wired in parallel
- Connecting cable
- Cable type: PVC



100755

CMS-R-BXO-SC

Read heads CMS, design B - with NO contact combinations, M8

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 36 x 26 mm
- NO contacts wired in parallel
- With plug connector M8



092024

CMS-R-BXP-05V

Read heads CMS, design B - with NO contact combinations, PVC

- In combination with evaluation unit CMS-E-AR
- Cube-shaped version, 36 x 26 mm
- NO contacts wired in series
- Connecting cable
- Cable type: PVC



105094

CMS-R-BZB-01P-AS1

Non-contact safety switch CMS-R-BZB-01P-AS1, with connecting cable and plug connector M12

- Safety switches with integrated read head and integrated evaluation unit.
- Operating distance 7 mm



097368

CMS-R-BZB-03V

Read heads design B for ESM, PVC

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 36 x 26 mm
- Connecting cable
- Cable type: PVC



103869

CMS-R-BZB-05P

Read heads, design B, for ESM, PUR

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 36 x 26 mm
- Connecting cable
- Cable type: PUR



100753

CMS-R-BZB-SC

Read heads, design B, for ESM, M8

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 36 x 26 mm
- Plug connector M8

**159518**

CMS-R-BZD-05V

Read heads CMS, design B - with NO contact combinations, PVC

- In combination with evaluation units ESM-BA...
- Cube-shaped version, 36 x 26 mm
- Connecting cable
- Cable type: PVC

**084574**

CMS-R-CXA-03V

Read heads CMS design C - with NO contact combinations, PVC

- In combination with evaluation units CMS-E-AR
- Cylindrical version M25
- NO contacts wired in parallel
- Connecting cable
- Cable type: PVC

**085739**

CMS-R-CXA-05V

Read heads CMS design C - with NO contact combinations, PVC

- In combination with evaluation units CMS-E-AR
- Cylindrical version M25
- NO contacts wired in parallel

- Connecting cable
- Cable type: PVC



084576

CMS-R-CXB-03V

Read heads CMS design C - with NO contact combinations, PVC

- In combination with evaluation units CMS-E-AR
- Cylindrical version M25
- NO contacts wired in series
- Connecting cable
- Cable type: PVC



084575

CMS-R-CXC-03V

Read heads CMS design C - with NC/NO contacts, PVC

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cylindrical version M25
- Connecting cable
- Cable type: PVC



103872

CMS-R-CXC-05P

Read heads CMS, design C - with NC/NO contacts, PUR

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cylindrical version M25
- Connecting cable
- Cable type: PUR

**085741**

CMS-R-CXC-05V

Read heads CMS design C - with NC/NO contacts, PVC

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cylindrical version M25
- Connecting cable
- Cable type: PVC

**103967**

CMS-R-CXC-SC

Read heads CMS, design C - with NC/NO contacts, M8

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cylindrical version M25
- Plug connector M8

**085633**

CMS-R-EXL-03V

Read heads CMS design E - with NO contact combinations, PVC

- In combination with evaluation units CMS-E-AR
- Cylindrical version M30
- NO contacts wired in parallel
- Connecting cable
- Cable type: PVC



085634

CMS-R-EXM-03V

Read heads CMS design E - with NC/NO contacts, PVC

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cylindrical version M30
- Connecting cable
- Cable type: PVC

**085743**

CMS-R-EXM-05V

Read heads CMS design E - with NC/NO contacts, PVC

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cylindrical version M30
- Connecting cable
- Cable type: PVC

**103969**

CMS-R-EXM-SC

Read heads CMS, design E - with NC/NO contacts, M8

- In combination with evaluation units CMS-E-BR/CMS-E-ER/CMS-E-FR
- Cylindrical version M30
- Plug connector M8

**085635**

CMS-R-EXN-03V

Read heads CMS design E - with NO contact combinations, PVC

- In combination with evaluation units CMS-E-AR
- Cylindrical version M30
- NO contacts wired in series
- Connecting cable

- Cable type: PVC

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eai@nt-rt.ru || сайт: <https://euchner.nt-rt.ru/>