

Предохранительные выключатели в прочном корпусе, с мониторингом блокировки, типа TZ

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eai@nt-rt.ru || сайт: <https://euchner.nt-rt.ru/>

SAFETY SWITCH TZ WITH GUARD LOCKING AND GUARD LOCK MONITORING



Description

The safety switch TZ has magnetic guard locking with additional interlocking monitoring system. Consequently, the position of the door and the solenoid can be monitored by the higher-level control system. Series TZ safety switches are switches of type 2. They differ in the locking method, solenoid operating voltage, actuating head, switching contacts used, as well as the connection.

Features

- Auxiliary release from the front
- Optionally with escape release
- LEDs for the function display
- Connection by cable entry or plug connector
- Max. 8 switching contacts permit flexible wiring



098718

TZ1LB024MVAB-C2159

Safety switch TZ, auxiliary release with triangular key

- Auxiliary release on the front, release with a triangular key according to DIN 22417

- Two LED displays, red and green
- Actuating head fitted left



079692

TZ1LE024BHA-C1902

Safety switch TZ, plug connector MR12, special wiring

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector MR12
- Actuating head fitted left



082095

TZ1LE024BHA-C1903

Safety switch TZ, plug connector MR10, auxiliary release

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted left



119367

TZ1LE024BHA-C2399

Safety switch TZ, plug connector MR10, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear with pushbutton
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted left



095902

TZ1LE024BHA10VAB-C2401

Safety switch TZ, plug connector MR10, without auxiliary release

- Without auxiliary release
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted left



119611

TZ1LE024BHA10VAB-C2402

Safety switch TZ, plug connector MR10, with escape release

- Escape release on the rear side with key button
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted left



083190

TZ1LE024BHAVFG-RC1924

Safety switch TZ, plug connector MR12

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR12
- Actuating head fitted left



085569

TZ1LE024BHAVFG-RC1971

Safety switch TZ, plug connector MR12, special wiring

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector MR12
- Actuating head fitted left

**082050**

TZ1LE024M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**089470**

TZ1LE024M-089470

Safety switch TZ, protective plate

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Actuating head fitted left

**083246**

TZ1LE024M-C1623

Safety switch TZ, without auxiliary release

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green

- Actuating head fitted left



083170

TZ1LE024M-C1684

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green
- Actuating head fitted left



087990

TZ1LE024M-C1815

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted left



089477

TZ1LE024M-C1816

Safety switch TZ, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Actuating head fitted left



095245

TZ1LE024M-C2087

Safety switch TZ, two cable entries

- Auxiliary release on the front
- Two cable entries M20x1.5
- Two LED displays, red and green
- Actuating head fitted left

**083164**

TZ1LE024M-R

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**083965**

TZ1LE024MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**085170**

TZ1LE024MVAB-C1623

Safety switch TZ, without auxiliary release

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green
- Actuating head fitted left



084820

TZ1LE024MVAB-C1684

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green
- Actuating head fitted left



089468

TZ1LE024MVAB-C1828

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted left



096487

TZ1LE024MVAB-C2082

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear with pushbutton
- Two LED displays, red and green
- Actuating head fitted left



113504

TZ1LE024MVAB-C2087

Safety switch TZ, two cable entries

- Auxiliary release on the front
- Two cable entries M20x1.5
- Two LED displays, red and green
- Actuating head fitted left

**089434**

TZ1LE024MVAB-R

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**096052**

TZ1LE024MVAB-RC2100

Safety switch TZ, without auxiliary release

- Without auxiliary release
- Two LED displays, red and green
- Actuating head fitted left

**089464**

TZ1LE024MVFG-RC1925

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left



054964

TZ1LE024PGOR8C

Safety switch TZ, plug connector MR8, auxiliary release

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR8
- Actuating head fitted left



084242

TZ1LE024RC18VAB

Safety switch TZ, plug connector RC18

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



092998

TZ1LE024RC18VAB-092998

Safety switch TZ, plug connector RC18, emergency release with rotary knob

- Emergency release on the front with rotary knob
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



093862

TZ1LE024RC18VAB-093862

Safety switch TZ, plug connector RC18, special wiring

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left

**091062**

TZ1LE024RC18VAB-C1803

Safety switch TZ, plug connectors RC18 and RC12, without auxiliary release

- Without auxiliary release
- Two LED displays, red and green
- Plug connector for switch connection
- Plug connector for enabling switch
- Actuating head fitted left

**088090**

TZ1LE024RC18VAB-C1823

Safety switch TZ, plug connector RC18, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left

**084246**

TZ1LE024RC18VAB-C1826

Safety switch TZ, plug connector RC18

- Auxiliary release on the front

- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



090352

TZ1LE024RC18VAB-C1828

Safety switch TZ, plug connector RC18, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



074260

TZ1LE024RC18VAB-C1937

Safety switch TZ, plug connector RC18, emergency release with rotary knob

- Emergency release on the front with rotary knob
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



097347

TZ1LE024RC18VAB-C2123

Safety switch TZ, plug connector RC18, emergency release with rotary knob, escape release with pushbutton

- Emergency release on the front with rotary knob
- Escape release on the rear with pushbutton
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



098297

TZ1LE024RC18VAB-C2140

Safety switch TZ, plug connector RC18, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear with pushbutton
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



086140

TZ1LE024SEM4AS1

Safety switch TZ ASi, plug connector M12 (closed-circuit current principle)

- Auxiliary release on the front
- Actuating head fitted left
- Plug connector M12



094422

TZ1LE024SEM4AS1-C1815

Safety switch TZ ASi, plug connector M12, escape release (closed-circuit current principle)

- Auxiliary release on the front
- Escape release on the rear side with key button
- Actuating head fitted left



090278

TZ1LE024SEM4AS1-C1937

Safety switch TZ ASi, plug connector M12, emergency release (closed-circuit current principle)

- Emergency release on the front with rotary knob
- Actuating head fitted left

**070828**

TZ1LE024SR11

Safety switch TZ, plug connector SR11

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted left

**093860**

TZ1LE024SR11-093860

Safety switch TZ, plug connector SR11, protective plate

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted left

**070886**

TZ1LE024SR11-C1684

Safety switch TZ, plug connector SR11, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green

- Plug connector SR11
- Actuating head fitted left



077044

TZ1LE024SR11-C1816

Safety switch TZ, plug connector SR11, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted left



083230

TZ1LE024SR11VAB-C1933

Safety switch TZ, plug connector SR11

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted left



046502

TZ1LE024SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left



089476

TZ1LE024SR6-C1638

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left



059694

TZ1LE024SR6-C1677

Safety switch TZ, plug connector SR6, protective plate

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left



083160

TZ1LE110M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left



083168

TZ1LE110M-R

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**088023**

TZ1LE110MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**094311**

TZ1LE110MVAB-C1828

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted left

**095992**

TZ1LE110MVAB-C2082

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear with pushbutton
- Two LED displays, red and green
- Actuating head fitted left



074917

TZ1LE110PGOR8C

Safety switch TZ, plug connector MR8, auxiliary release

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR8
- Actuating head fitted left



046503

TZ1LE110SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left



083166

TZ1LE220M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left



093770

TZ1LE220M-C1684

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green
- Actuating head fitted left

**088029**

TZ1LE220MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**046504**

TZ1LE220SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left

**098717**

TZ1RB024MVAB-C2159

Safety switch TZ, auxiliary release with triangular key

- Auxiliary release on the front, release with a triangular key according to DIN 22417
- Two LED displays, red and green
- Actuating head fitted right



079693

TZ1RE024BHA-C1902

Safety switch TZ, plug connector MR12, special wiring

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector MR12
- Actuating head fitted right



082096

TZ1RE024BHA-C1903

Safety switch TZ, plug connector MR10, auxiliary release

- Emergency release on the front
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted right



119368

TZ1RE024BHA-C2399

Safety switch TZ, plug connector MR10, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear with pushbutton
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted right



095903

TZ1RE024BHA10VAB-C2401

Safety switch TZ, plug connector MR10, without auxiliary release

- Without auxiliary release
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted right



119612

TZ1RE024BHA10VAB-C2402

Safety switch TZ, plug connector MR10, with escape release

- Escape release on the rear side with key button
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted right



083191

TZ1RE024BHAVFG-RC1924

Safety switch TZ, plug connector MR12

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR12
- Actuating head fitted right



085570

TZ1RE024BHAVFG-RC1971

Safety switch TZ, plug connector MR12, special wiring

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector MR12
- Actuating head fitted right

**082051**

TZ1RE024M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right

**089471**

TZ1RE024M-089471

Safety switch TZ, protective plate

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Actuating head fitted right

**083247**

TZ1RE024M-C1623

Safety switch TZ, without auxiliary release

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green

- Actuating head fitted right



083171

TZ1RE024M-C1684

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green
- Actuating head fitted right



087991

TZ1RE024M-C1815

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted right



096901

TZ1RE024M-C1816

Safety switch TZ, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Actuating head fitted right



095253

TZ1RE024M-C2087

Safety switch TZ, two cable entries

- Auxiliary release on the front
- Two cable entries M20x1.5
- Two LED displays, red and green
- Actuating head fitted right

**083165**

TZ1RE024M-R

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right

**083966**

TZ1RE024MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right

**085171**

TZ1RE024MVAB-C1623

Safety switch TZ, without auxiliary release

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green
- Actuating head fitted right



088084

TZ1RE024MVAB-C1684

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green
- Actuating head fitted right



089469

TZ1RE024MVAB-C1828

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted right



096488

TZ1RE024MVAB-C2082

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear with pushbutton
- Two LED displays, red and green
- Actuating head fitted right



098205

TZ1RE024MVAB-C2087

Safety switch TZ, two cable entries

- Auxiliary release on the front
- Two cable entries M20x1.5
- Two LED displays, red and green
- Actuating head fitted right

**083233**

TZ1RE024MVAB-R

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right

**096051**

TZ1RE024MVAB-RC2100

Safety switch TZ, without auxiliary release

- Without auxiliary release
- Two LED displays, red and green
- Actuating head fitted right

**089465**

TZ1RE024MVFG-RC1925

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



059920

TZ1RE024PGOR8C

Safety switch TZ, plug connector MR8, auxiliary release

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR8
- Actuating head fitted right



084243

TZ1RE024RC18VAB

Safety switch TZ, plug connector RC18

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



092999

TZ1RE024RC18VAB-092999

Safety switch TZ, plug connector RC18, emergency release with rotary knob

- Emergency release on the front with rotary knob
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



093863

TZ1RE024RC18VAB-093863

Safety switch TZ, plug connector RC18, special wiring

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right

**091063**

TZ1RE024RC18VAB-C1803

Safety switch TZ, plug connectors RC18 and RC12, without auxiliary release

- Without auxiliary release
- Two LED displays, red and green
- Plug connector for switch connection
- Plug connector for enabling switch
- Actuating head fitted right

**088091**

TZ1RE024RC18VAB-C1823

Safety switch TZ, plug connector RC18, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right

**084247**

TZ1RE024RC18VAB-C1826

Safety switch TZ, plug connector RC18

- Auxiliary release on the front

- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



090353

TZ1RE024RC18VAB-C1828

Safety switch TZ, plug connector RC18, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



074261

TZ1RE024RC18VAB-C1937

Safety switch TZ, plug connector RC18, emergency release with rotary knob

- Emergency release on the front with rotary knob
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



097348

TZ1RE024RC18VAB-C2123

Safety switch TZ, plug connector RC18, emergency release with rotary knob, escape release with pushbutton

- Emergency release on the front with rotary knob
- Escape release on the rear with pushbutton
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



098298

TZ1RE024RC18VAB-C2140

Safety switch TZ, plug connector RC18, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear with pushbutton
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



086141

TZ1RE024SEM4AS1

Safety switch TZ ASi, plug connector M12 (closed-circuit current principle)

- Auxiliary release on the front
- Actuating head fitted right
- Plug connector M12



094423

TZ1RE024SEM4AS1-C1815

Safety switch TZ ASi, plug connector M12, escape release (closed-circuit current principle)

- Auxiliary release on the front
- Escape release on the rear side with key button
- Actuating head fitted right



090279

TZ1RE024SEM4AS1-C1937

Safety switch TZ ASi, plug connector M12, emergency release (closed-circuit current principle)

- Emergency release on the front with rotary knob
- Actuating head fitted right

**070826**

TZ1RE024SR11

Safety switch TZ, plug connector SR11

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted right

**093861**

TZ1RE024SR11-093861

Safety switch TZ, plug connector SR11, protective plate

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted right

**094343**

TZ1RE024SR11-094343

Safety switch TZ, plug connector SR11, emergency release with rotary knob

- Emergency release on the front with rotary knob
- Protective plate for switch head
- Two LED displays, red and green

- Plug connector SR11
- Actuating head fitted right



070884

TZ1RE024SR11-C1684

Safety switch TZ, plug connector SR11, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted right



077042

TZ1RE024SR11-C1816

Safety switch TZ, plug connector SR11, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted right



083231

TZ1RE024SR11VAB-C1933

Safety switch TZ, plug connector SR11

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted right



046190

TZ1RE024SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right



070529

TZ1RE024SR6-C1638

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right



059692

TZ1RE024SR6-C1677

Safety switch TZ, plug connector SR6, protective plate

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right



083161

TZ1RE110M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right

**089475**

TZ1RE110M-C1684

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green
- Actuating head fitted right

**089448**

TZ1RE110M-R

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right

**088024**

TZ1RE110MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



088063

TZ1RE110MVAB-C1623

Safety switch TZ, without auxiliary release

- Without auxiliary release
- Protective plate for switch head
- Two LED displays, red and green
- Actuating head fitted right



094312

TZ1RE110MVAB-C1828

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted right



095103

TZ1RE110MVAB-C2082

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear with pushbutton
- Two LED displays, red and green
- Actuating head fitted right



074916

TZ1RE110PGOR8C

Safety switch TZ, plug connector MR8, auxiliary release

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR8
- Actuating head fitted right

**046191**

TZ1RE110SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right

**083167**

TZ1RE220M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right

**093771**

TZ1RE220M-C1684

Safety switch TZ, escape release with pushbutton

- Auxiliary release on the front
- Escape release on the rear side with pushbutton
- Two LED displays, red and green
- Actuating head fitted right



088030
 TZ1RE220MVAB
 Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



051879
 TZ1RE220SR6
 Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right



082083
 TZ2LE024BHA-C1903
 Safety switch TZ, plug connector MR10, auxiliary release

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted left



090559

TZ2LE024M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**089460**

TZ2LE024M-C1815

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted left

**087992**

TZ2LE024M-C1816

Safety switch TZ, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Actuating head fitted left

**089445**

TZ2LE024M-R

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left



088070

TZ2LE024MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left



089455

TZ2LE024MVAB-C1823

Safety switch TZ, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Actuating head fitted left



087290

TZ2LE024MVAB-C1828

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted left



075955

TZ2LE024RC18VAB-C1803

Safety switch TZ, plug connectors RC18 and RC12, without auxiliary release

- Without auxiliary release
- Two LED displays, red and green
- Plug connector for switch connection
- Plug connector for enabling switch
- Actuating head fitted left



085180

TZ2LE024RC18VAB-C1826

Safety switch TZ, plug connector RC18

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



093103

TZ2LE024RC18VAB-C1828

Safety switch TZ, plug connector RC18, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



100778

TZ2LE024RC18VAB-C1937

Safety switch TZ, plug connector RC18, emergency release with rotary knob

- Emergency release on the front with rotary knob
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted left



086990

TZ2LE024SEM4AS1

Safety switch TZ ASi, plug connector M12 (open-circuit current principle)

- Auxiliary release on the front
- Actuating head fitted left
- Plug connector M12



070958

TZ2LE024SR11

Safety switch TZ, plug connector SR11

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted left



079660

TZ2LE024SR11-C1815

Safety switch TZ, plug connector SR11, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted left



049159

TZ2LE024SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left

**076294**

TZ2LE024SR6-C1638

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left

**059852**

TZ2LE024SR6-C1677

Safety switch TZ, plug connector SR6, protective plate

- Auxiliary release on the front
- Protective plate for switch head
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left

**046915**

TZ2LE024SR6-R

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green

- Plug connector SR6
- Actuating head fitted left



083162
TZ2LE110M
Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left



088025
TZ2LE110MVAB
Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left



052914
TZ2LE110SR6
Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left



088031

TZ2LE220M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**088027**

TZ2LE220MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted left

**045450**

TZ2LE220SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted left

**082084**

TZ2RE024BHA-C1903

Safety switch TZ, plug connector MR10, auxiliary release

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector MR10
- Actuating head fitted right



090560
TZ2RE024M
Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



089461
TZ2RE024M-C1815
Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted right



087993
TZ2RE024M-C1816
Safety switch TZ, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Actuating head fitted right



089446
TZ2RE024M-R
Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



088071

TZ2RE024MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



089456

TZ2RE024MVAB-C1823

Safety switch TZ, release with pushbutton

- Release on the front with pushbutton
- Two LED displays, red and green
- Actuating head fitted right



087291

TZ2RE024MVAB-C1828

Safety switch TZ, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Actuating head fitted right



077149

TZ2RE024RC18VAB-C1803

Safety switch TZ, plug connectors RC18 and RC12, without auxiliary release

- Without auxiliary release
- Two LED displays, red and green
- Plug connector for switch connection
- Plug connector for enabling switch
- Actuating head fitted right



085181

TZ2RE024RC18VAB-C1826

Safety switch TZ, plug connector RC18

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



093104

TZ2RE024RC18VAB-C1828

Safety switch TZ, plug connector RC18, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



100777

TZ2RE024RC18VAB-C1937

Safety switch TZ, plug connector RC18, emergency release with rotary knob

- Emergency release on the front with rotary knob
- Two LED displays, red and green
- Plug connector M23 (RC18)
- Actuating head fitted right



086991

TZ2RE024SEM4AS1

Safety switch TZ ASi, plug connector M12 (open-circuit current principle)

- Auxiliary release on the front
- Actuating head fitted right
- Plug connector M12



070957

TZ2RE024SR11

Safety switch TZ, plug connector SR11

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted right



079661

TZ2RE024SR11-C1815

Safety switch TZ, plug connector SR11, escape release with key button

- Auxiliary release on the front
- Escape release on the rear side with key button
- Two LED displays, red and green
- Plug connector SR11
- Actuating head fitted right

**049102**

TZ2RE024SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right

**055819**

TZ2RE024SR6-C1638

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right

**059699**

TZ2RE024SR6-C1677

Safety switch TZ, plug connector SR6, protective plate

- Auxiliary release on the front
- Protective plate for switch head

- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right



083163
TZ2RE110M
Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



088026
TZ2RE110MVAB
Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



049238
TZ2RE110SR6
Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right



088032

TZ2RE220M

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



088028

TZ2RE220MVAB

Safety switch TZ

- Auxiliary release on the front
- Two LED displays, red and green
- Actuating head fitted right



047937

TZ2RE220SR6

Safety switch TZ, plug connector SR6

- Auxiliary release on the front
- Two LED displays, red and green
- Plug connector SR6
- Actuating head fitted right

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eai@nt-rt.ru || сайт: <https://euchner.nt-rt.ru/>