

Предохранительные выключатели в пластиковом корпусе, с металлической головкой, типа SGP

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eai@nt-rt.ru || сайт: <https://euchner.nt-rt.ru/>

SAFETY SWITCH SGP



Safety switch SGP

The SGP safety switch is the counterpart to the STP safety switch. The entire STP and SGP product families have the same metal actuating head and the same actuators.

This means that the STP (safety switch with guard locking) or SGP (without guard locking) safety switches can be used in a system, depending on the requirements.

EUCHNER offers the SGP product series with switching elements with different contact combinations (positively driven, positively driven contact / normally open contact).

Dual-channel wiring for the highest possible safety level is possible for all variants.

With the ability of the switching contacts to switch a minimum current of 1 mA, the SGP safety switch is also suitable for mode on safe control systems.

Features

- Same drilling pattern as STP, same actuators
- Same metal actuating head for the highest requirements
- Flexible connection options via three cable entries
- High degree of protection IP 67



100809

SGP-TW-1E-2131AC-M

Safety switch SGP-TW, cable entry M20 x 1.5

- TWIN function (two actuating heads)
- 3 x cable entry M20 x 1.5
- 3 pos. driven contacts

- 1 NO contacts



099900

SGP-TW-1E-2131AC-M-S1

Safety switch SGP-TW, cable entry M20 x 1.5

- TWIN function (two actuating heads)
- 3 x cable entry M20 x 1.5
- 3 pos. driven contacts
- 1 NO contacts
- Additional lock on the switch head



097705

SGP1E-2121A-M

Safety switch SGP, cable entry M20 x 1.5

- 3 x cable entry M20 x 1.5
- 4 positively driven, positively driven contacts



097706

SGP1E-2131A-M

Safety switch SGP, cable entry M20 x 1.5

- 3 x cable entry M20 x 1.5
- 3 pos. driven contacts
- 1 NO contacts



097707

SGP1E-3131A-M

Safety switch SGP, cable entry M20 x 1.5

- 3 x cable entry M20 x 1.5
- 2 pos. driven contacts
- 2 NO contacts

**100907**

SGP2E-2131A-9C-DCX

Safety switch SGP, plug connector MR9

- Plug in 9 pin MR9 (without PE)
- 3 pos. driven contacts
- 1 NO contacts

**099084**

SGP2E-2131ASR11

Safety switch SGP, plug connector SR11

- Plug connector(s) SR11, 11-pole (without PE)
- 3 pos. driven contacts
- 1 NO contacts

**104022**

SGP2E-538ASR6

Safety switch SGP, plug connector SR6

- Plug connector(s) SR6, 6-pin (without PE)
- 2 pos. driven contacts





099126

SGP3E-538ASEM4AS1

Safety switch SGP ASI, plug connector M12

- AS Interface
- Plug connector(s) M12, 4-pin
- 2 pos. driven contacts
- Internal LED function display



169844

SGP3E-538ASFM5C2628

Safety switch SGP, plug connector(s) M12

- M12 plug connector(s), 5-pin (4 poles connected)
- 2 pos. driven contacts

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: eai@nt-rt.ru || сайт: <https://euchner.nt-rt.ru/>