

# Ручные пульты с кнопкой согласования, типа ZSA и ZSR

## Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: [eai@nt-rt.ru](mailto:eai@nt-rt.ru) || сайт: <https://euchner.nt-rt.ru/>

# ENABLING SWITCH ZSA/ZSR



- Housing G1
- 2-/3-stage function
- Single-channel or dual-channel version
- Kit without connecting cable



**072969**

ZSA072969C1983

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 15 m
- LED



**086681**

ZSA086681C1979

ZSA, 3-stage, with LEDs and plug connector MR8

- Housing G1
- 3-stage function
- Plug connector
- 2 LEDs

- Actuator for safety switch NZ.VZ or TZ



**086707**

ZSA086707C1983

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 10 m
- LED



**092141**

ZSA092141C2038

ZSA, 3-stage, with cable and plug connector RC12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 5 m
- Direct connection to safety switch



**097567**

ZSA097567C2038

ZSA, 3-stage, with cable and plug connector RC12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 10 m
- Direct connection to safety switch



**099495**

ZSA099495C2038

ZSA, 3-stage, with cable and plug connector RC12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 15 m
- Direct connection to safety switch



**070750**

ZSA1-1

Pushbutton kit ZSA, 2-stage

- Housing G1
- 2-stage function
- Kit without connecting cable



**070800**

ZSA1-2

Pushbutton kit ZSA, 2-stage

- Housing G1
- 2-stage function
- Kit without connecting cable



**070736**

ZSA1-3

Pushbutton kit ZSA, 2-stage

- Housing G1
- 2-stage function
- Kit without connecting cable



**100873**

ZSA100873C2038

ZSA, 3-stage, with cable and plug connector RC12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 25 m
- Direct connection to safety switch



**104231**

ZSA1A2G01AC2246

ZSA, 2-stage with cable

- Housing G1
- 2-stage function
- Straight connecting cable, 1 m
- Cable holder



**097909**

ZSA1A2G07A

ZSA, 2-stage with cable

- Housing G1
- 2-stage function
- Straight connecting cable, 7 m



**082557**

ZSA1A2L25AC1909

ZSA, 2-stage with cable

- Housing G1
- 2-stage function
- Straight connecting cable, 2.5 m
- Wall holder



**094321**

ZSA1A2S05A

ZSA, 2-stage with cable

- Housing G1
- 2-stage function
- Coiled connecting cable, 5 m



**082524**

ZSA1A5G05AC1917

ZSA, 2-stage with cable

- Housing G1
- 2-stage function
- Straight connecting cable, 5 m



**095144**

ZSA1A5G10AC1917

ZSA, 2-stage with cable

- Housing G1
- 2-stage function
- Straight connecting cable, 10 m



**070734**

ZSA2-1

Enabling switch kit ZSA, 3-stage

- Housing G1
- 3-stage function
- Kit without connecting cable



**070735**

ZSA2-2

Enabling switch kit ZSA, 3-stage

- Housing G1
- 3-stage function
- Kit without connecting cable



**070792**

ZSA2-4

Enabling switch kit ZSA, 3-stage

- Housing G1
- 3-stage function
- Kit without connecting cable



**095497**

ZSA2-4-10C1903

ZSA, 3-stage, built-in plug connector MR10

- Housing G1
- 3-stage function
- Plug connector MR10

**098531**

ZSA2-4-C2151

ZSA, 3-stage, built-in plug connector MR7

- Housing G1
- 3-stage function
- Plug connector MR7

**098533**

ZSA2-4-C2152

ZSA, 3-stage, built-in plug connector MR5

- Housing G1
- 3-stage function
- Plug connector MR5

**055402**

ZSA2A1G05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 5 m





**055403**

ZSA2A1G10A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 10 m



**057089**

ZSA2A1L15AC1689

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 1.5 m
- Wall holder



**072728**

ZSA2A1L25AC1689

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 2.5 m
- Wall holder



**055404**

ZSA2A1S05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Coiled connecting cable, 5 m

**099371**

ZSA2A2G02A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 2 m

**055406**

ZSA2A2G05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 5 m

**070741**

ZSA2A2G05CC1714

ZSA, 3-stage, with cable and plug connector RC17

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 5 m



**073289**

ZSA2A2G05CC1770

ZSA, 3-stage, with cable and plug connector RC12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 5 m



**055407**

ZSA2A2G10A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 10 m



**057007**

ZSA2A2G15A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 15 m



**075807**

ZSA2A2G20A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 20 m



**078939**

ZSA2A2G25A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 25 m



**070731**

ZSA2A2L12CC1725

ZSA, 3-stage, with cable and plug connector UT23

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 1.2 m



**055408**

ZSA2A2S05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Coiled connecting cable, 5 m



**057010**

ZSA2A2S05AC1643

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Coiled connecting cable, 5 m

**070784**

ZSA2A3G05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 5 m

**070785**

ZSA2A3G10A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 10 m

**070786**

ZSA2A3S05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Coiled connecting cable, 5 m



**070764**

ZSA2A4G05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 5 m



**091547**

ZSA2A4G05C-C2032

ZSA, 3-stage, with cable and plug connector RC17

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 5 m



**092738**

ZSA2A4G05C-C2041

ZSA, 3-stage, with cable and plug connector RC17

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 5 m



**070765**

ZSA2A4G10A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 10 m



**073300**

ZSA2A4G20A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 20 m



**086788**

ZSA2A4L25AC1689

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 2.5 m
- Wall holder



**070766**

ZSA2A4S05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Coiled connecting cable, 5 m



**091580**

ZSA2B2CAS1

ZSA, 3-stage, AS-Interface

- Housing G1
- 3-stage function
- Positively driven contacts
- Dual-channel version



**055410**

ZSA2B2G05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 5 m



**057097**

ZSA2B2G05B-C1662

ZSA, 3-stage, with cable and plug connector SS4

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 5 m
- Direct connection to safety switch





**055411**

ZSA2B2G10A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 10 m

**057100**

ZSA2B2G10B

ZSA, 3-stage, with cable and plug connector C16-1

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 10 m

**057098**

ZSA2B2G10B-C1662

ZSA, 3-stage, with cable and plug connector SS4

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 10 m
- Direct connection to safety switch

**072870**

ZSA2B2G15CC1926

ZSA, 3-stage, with cable and plug connector SVM5

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 15 m



**086206**

ZSA2B2G25CC1926

ZSA, 3-stage, with cable and plug connector SVM5

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 25 m



**169871**

ZSA2B4G02CC2322

ZSA, 3-stage, with cable and plug connector M12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 2 m



**170949**

ZSA2B4G02CC2630

ZSA, 3-stage, with cable and plug connector M12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 2 m



**072961**

ZSA2B4G05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 5 m



**070788**

ZSA2B4G10B

ZSA, 3-stage, with cable and plug connector C16-1

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 10 m



**077489**

ZSA2B4G10CC1830

ZSA, 3-stage, with cable and plug connector HAN10

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 10 m
- Increased actuating force



**110560**

ZSA2B4G10CC2322

ZSA, 3-stage, with cable and plug connector M12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 10 m



**170950**

ZSA2B4G10CC2630

ZSA, 3-stage, with cable and plug connector M12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 10 m



**165899**

ZSA2B4G15CC2322

ZSA, 3-stage, with cable and plug connector M12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 15 m



**170951**

ZSA2B4G15CC2630

ZSA, 3-stage, with cable and plug connector M12

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 15 m



**168977**

ZSA2B4G20AC2527

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Straight connecting cable, 20 m



**079870**

ZSA2B4G20B

ZSA, 3-stage, with cable and plug connector C16-1

- Housing G1
- 3-stage function
- Straight connecting cable with plug connector, 20 m



**085118**

ZSA2B4S05A

ZSA, 3-stage with cable

- Housing G1
- 3-stage function
- Coiled connecting cable, 5 m



**055423**

ZSR2A1G05A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Straight connecting cable, 5 m
- Including holder



**055424**

ZSR2A1G10A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Straight connecting cable, 10 m
- Including holder



**055425**

ZSR2A1S05A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Coiled connecting cable, 5 m
- Including holder



**055427**

ZSR2A2G05A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Straight connecting cable, 5 m
- Including holder



**055428**

ZSR2A2G10A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Straight connecting cable, 10 m
- Including holder

**055429**

ZSR2A2S05A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Coiled connecting cable, 5 m
- Including holder

**097609**

ZSR2A4G05A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Straight connecting cable, 5 m
- Including holder

**104085**

ZSR2A4S05A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2

- Coiled connecting cable, 5 m
- Including holder



**055431**

ZSR2B2G05A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Straight connecting cable, 5 m
- Including holder



**055432**

ZSR2B2G10A

ZSR, housing G2, 3-stage, with cable

- 3-stage function
- Housing G2
- Straight connecting cable, 10 m
- Including holder



## По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +(727)345-47-04

**Беларусь** +(375)257-127-884

**Узбекистан** +998(71)205-18-59

**Киргизия** +996(312)96-26-47

эл.почта: [eai@nt-rt.ru](mailto:eai@nt-rt.ru) || сайт: <https://euchner.nt-rt.ru/>